Instructions for 1500 Focus[™] Steamer





IMPORTANT: Only use distilled water.



HIGH TEMPERATURE STEAM. Do not point spray gun at yourself or other people.

BEFORE USE

Fill up the water tank with **distilled water** via the opening at the top of the machine. Plug the Focus[™] into a grounded 15 amp wall outlet.

OPERATING THE FOCUS™



1 Hold down the pump switch for 15 seconds.

2 Turn the heater on. The heater light will be on while the machine is heating up. Once the light turns off the heater is at temperature and the steamer is ready to use.

CONTINUOUS FILL CAPACITY

The Focus[™] Steamer features continuous fill capacity, meaning that you do not have to wait for the machine to cool down before refilling the tank. Water can be added to the tank while the machine is running. To refill the tank, turn on pump again for 15 seconds.

AFTER USE

Make sure all fluid is out of the machine before storing.
Store machine in a dry area in the upright position.

ATTENTION: Do not expose to rain. Store indoors.

ATTENTION: If storing machine in freezing temperatures, be sure that the machine and solution system are completely drained and dry.



SAFETY INFORMATION Explosion hazard: Do not operate with flammable liquids in or around the unit.

